




## Remove Display

Written By: Sandy Qualey-Dobson



## Step 1 — Remove the Display



- Using the T5 bit in the Framework Screwdriver, unscrew the 4 fasteners connecting the Display to the Top Cover.
- The Display is now fully unattached to the Top Cover, you can gently lift it up from the corner using your fingernail.

 Be sure to only handle the Display by the side edges and avoid touching the bottom area.